

Activity 5: Use WinHex to Examine NTFS Disks

Objectives:

- Become familiar with the WinHex forensics tool.
- Use WinHex to become familiar with different file types.
- Use WinHex to explore and become familiar with the MFT, including headers and attributes.

Part 1: Explore different file types.

The first part can be done on our local device, we use Microsoft word to create a document called, ‘Mywordnew.doc’, and this Word 97-2003 document will encompass the text, “This is a test.” Then we need to open WinHex and find the .doc we created and copy the file hexadecimal header D0 CF 11 E0 A1 B1 1A E1 to the next new document.

Header .doc




Figure 1: Header for Word 97-2003 .doc file.

These steps are then repeated for the following file types:

- .xls
- .docx
- .xlsx
- .jpg
- .png

Screenshots and text for each file type can be found below.

Header.xls

Offset	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
000000000	D0	CF	11	E0	A1	B1	1A	E1	00	00	00	00	00	00	00	

Đĩ ài± á

Figure 2. Header for Excel 97-2003 Workbook.xls.

Header.docx

Offset	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
000000000	50	4B	03	04	14	00	06	00	08	00	00	00	21	00	DF	A4

PK ! ß¤

Figure 3. Header for Word 2007 Document.docx.

Header.xlsx

Offset	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
000000000	50	4B	03	04	14	00	06	00	08	00	00	21	00	41	37	

PK ! A7

Figure 4. Header for Excel 2007 Workbook.xlsx.

Part 2: Explore MFT.

The second part of this activity requires we create a file named lab1part2.txt, containing the following lines.

- A countryman between two layers is like a fish between two cats.
- A slip of the foot you may soon recover, but a slip of the tongue you may never get over.
- An investment in knowledge always pays the best interest.
- Drive thy business or it will drive there.




Figure 8. Creating lab1part2.txt file.

We then need to open WinHex as administrator and navigate the options to change it to read-only mode.




Figure 9. Set Winhex to Read-Only mode.

After that, we need to select the drive that has our lab1part2.txt file for us to examine. To do this we need to go into tools then open disk. Selecting C: drive.




Figure 10. Choosing the C: drive as our disk to open.

Now before we can begin analyzing our created .txt file we first need to change the data interpreter settings. So we need to open that up and check the Win32 FILETIME (64 bit) before we can progress.




Figure 11. Setting Data interpreter to Win32 FILETIME (64 bit).

Once that is selected and changed we can now examine our lab1part2.txt file and find the beginning.




Figure 12. Beginning of the record for lab1part2.txt

Now in order to perform the 0x10 attribute, we click the beginning of the MFT record and drag until the offset counter is 0x38.




Figure 13. The start of attribute 0x10 at offset 0x38

The files created date and time can be found at offset 0x10 to 0x1f from the beginning of attribute 0x10.

Figure 14. File created date and time.

Questions:

1. According to the data interpreter, what are the file creation date and time for the file lab1part.txt?

- a. According to the data interpreter, the create date and time is 11/22/2020 07:22:57.

Figure 15. Data Interpreter's file created date and time.

2. Using File Explorer and go to the folder where the lab1part2.txt located, right-click on the arrow near “Size” or “Name” and select the “Date created”. Now the “Date created” time is also displayed.

- a. The file explore says that the txt file's created date and time is **11/01/2020 at 11:22 PM**.

Name	Date modified	Type	Size	Date created
lab1part2	11/21/2020 11:32 PM	Text Document	1 KB	11/21/2020 11:22 PM

Figure 16. File Explorer's date and time creation.

3. Compare this time and the time you got from the data interpreter. Are they the same? If not, why?

- a. The time for the data interpreter is ahead of the time the file explorer said it to be. We can find out that the reason the times differ is due to the data interpreter's timestamp. We just need to change the time to UTC. To do so go to **options then press Data Interpreter** and check the **Timestamps based on the UTC** box. After doing this, the time and data

become identical. The reason behind the time difference is that the file explorer's default time creation timestamp follows UTC time and the Data interpreter does not.




Figure 17. Checking 'Timestamps based on UTC'.

Name	Date modified	Type	Size	Date created
lab1part2	11/21/2020 11:32 PM	Text Document	1 KB	11/21/2020 11:22 PM

Below the table, the file content is shown in hex and ASCII. The timestamp 'FILETIME: 11/21/2020 07:22:57' is highlighted in blue, indicating it has been modified by the Data Interpreter.

Figure 18. Data Interpreter time now matches File explorer time.

4. What is the size of the MFT record?

- a. The size of the MFT record is, in big-endian, offset 23C3FB2400 00 04 00 00. We can find that at offset 0x1C to 0x1F.

Offset	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F	10	11	12	13	14	15	16	17	18	19	1A	1B	1C	1D	1E	1F					
23C3FB2400	46	49	4C	45	30	00	03	00	E2	51	04	0D	00	00	00	0F	00	02	00	38	00	01	00	A8	02	00	00	00	04	00	00						
23C3FB2420	00	00	00	00	00	00	00	00	09	00	00	00	49	6A	08	00	08	00	20	74	00	00	00	00	A8	02	00	00	00	60	00	00					
23C3FB2440	00	00	00	00	00	00	00	00	48	00	00	00	18	00	00	00	89	BC	2	Data Interpreter	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
23C3FB2460	AB	6D	38	FA	A4	C0	D6	01	55	F5	05	9E	A1	C0	D6	01	20	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00					
23C3FB2480	00	00	00	00	B7	19	00	00	00	00	00	00	00	00	00	00	70	A4	0	8 Bit (±): 0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0		
23C3FB24A0	00	00	00	00	00	00	08	00	5A	00	00	00	18	00	01	00	A8	6A	0	16 Bit (±): 1,024	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
23C3FB24C0	55	F5	05	9E	A1	C0	D6	01	55	F5	05	9E	A1	C0	D6	01	55	F5	0	32 Bit (±): 1,024	0	UÖ	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
23C3FB24E0	D6	00	00	00	00	00	00	00	20	00	00	00	00	00	00	00	0C	02	4	FILETIME: ?	0	Ö	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
23C3FB2500	31	00	2E	00	54	00	58	00	54	00	00	00	00	00	00	00	30	00	0	?	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
23C3FB2520	EC	00	00	00	19	00	01	00	09	0A	09	00	00	00	17	00	99	BC	22	AD	00	00	D6	01	55	BE	0F	0F	A1	00	D6	01	0				

Figure 19. The size of the MTF Record.

5. What is the length of the header for the MFT record?

- a. The header length for the MFT record is **0x38**. Found at offset **0x00 to 0x14**.

Offset	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F	10	11	12	13	14	15		
23C3FB2400	46	49	4C	45	30	00	03	00	E2	5E	51	04	0D	00	00	00	0F	00	02	00	38	00	00	
23C3FB2420	00	00	00	00	00	00	00	00	09	00	00	00	00	00	00	00	08	00	20	74	00	00	00	
23C3FB2440	00	00	00	00	00	00	00	00	Data Interpreter								9	BC	22	4D	A0	C0	I	
23C3FB2460	AB	6D	38	F													0	00	00	00	00	00	00	
23C3FB2480	00	00	00	00	00	00	00	00									0	A4	0A	85	02	00	00	
23C3FB24A0	00	00	00	00	00	00	00	00									8	6A	08	00	00	00	00	
23C3FB24C0	55	F5	05	9													5	F5	05	9E	A1	C0	I	
23C3FB24E0	D6	00	00	00	00	00	00	00									C	02	4C	00	41	00	00	
23C3FB2500	31	00	2E	0													0	00	00	00	78	00	00	
23C3FB2520	5C	00	00	00	00	18	00	01	00	A8	6A	08	00	00	00	17	00	89	BC	22	4D	A0	C0	I
23C3FB2540	55	F5	05	9E	A1	C0	D6	01									D8	00	00	00	00	00	00	

Figure 20. The length of the MTF record's header is **0x38**.

6. What are the file's last modified date and time?

- a. The last modified time and date are **11/21/2020 11:32 PM or 11/21/2020 23:32:22** according to the data interpreter. We can find the modified date and time at offset **0x20 to 0x27**.

Name	Date modified	Type	Size	Date created
lab1part2	11/21/2020 11:32 PM	Text Document	1 KB	11/21/2020 11:22 PM
0 00 00 00 00 00 08 00 5A 00 00 00 18 00 01 00 A8 6A 08 00 00 00 17 00 89 BC 22 4D A0 C0 D6				
5 F5 05 9E A1 C0 D6 01 55 F5 05 9E A1 C0 D6 01 55 F5 05 9E A1 C0 D6 01 D8 00 00 00 00 00 00 00				
6 00 00 00 00 00 00 00 20 00 00 00 00 00 00 00 00 0C 02 4C 00 41 00 42 00 31 00 50 00 41 00 7E				
1 00 00 2E 00 54 00 58 00 54 00 00 00 00 00 00 00 30 00 00 00 78 00 00 00 00 00 00 00 00 00 00 07				
2 00 00 00 18 00 01 Data Interpreter 55 F5 05 9E A1 C0 D6 01 55 F5 05 9E A1 C0 D6 01 D6 00 00 00 00 00 00 00				
3 00 00 00 00 00 00 00 8 Bit (±): 85 61 00 72 00 74 00 32 00 2E 00 74				
3 00 74 00 00 00 00 16 Bit (±): -2,731 00 00 04 00 10 00 00 00 18 00 00				
6 8F 87 A1 8E 2C EE 32 Bit (±): -1,643,776,683 F0 00 00 00 00 00 18 00 00 00 01				
6 00 00 00 18 00 00 FILETIME: 11/21/2020 20 62 65 74 77 65 65 6E 20 74 77				
3 6C 61 79 65 72 73 23:32:22 73 68 20 62 65 74 77 65 65 6E 08				

Figure 21. File last modified data based on UTC time.

7. What is the file name? In which attribute and at what position can you find it?

- a. From lecture 5's handout, if the file name is longer than eight characters there are two attributes **0x30**. Since our file name is longer than 8 characters we fall into this case. That means we have a short file name and a long file name.
- b. Short file names are found at offset **0x5A** from the first **0x30** attribute. Our short file name is LAB1PA~1.TXT

Figure 22. Short name 0x5A from the first 0x30 attribute.

- c. Long file names are found at offset 0x5A from the second 0x30 attribute. Our short file name is lab1part2.txt.

Figure 23. Long name 0x5A from the second 0x30 attribute.

8. Is this file a resident file or a nonresident file? Where can you find the evidence?

- a. The resident/nonresident flags exist at offset 0x08 from attribute 0x80. In this case, it is a resident file.

Figure 24. Resident flag set to 0x00 - resident file

9. In which attribute can you find the data run? Where is the start of the data run?

- a. The start of the data run for a resident exists at offset 0x18 from attribute 0x80.

Figure 25. Start of data run for the resident file. Offset 0x18 from 0x80.